

#8504 MCOR Conversion Kit installation Guide for #8401 Pedal Assembly

Step 1: Remove screw



Step 2: Remove plate where Mcor is mounted



Step 3: Remove male from pedal group



Step 4: Insert #8504 MCOR conversion kit and place screw back on

