

## INCLUDED:

MADJAX CLAYS BASKET BRACKETS HARDWARE PACK



Remove bolts from front struts.
Retain all factory hardware.
You will need it later.







Using retained factory hardware, attach brackets to front struts.
Tighten bolts.





Attach clays basket to brackets on both sides using hardware from pack 1.

VISIT WWW.MYMADMJAX.COM FOR MORE INSTALLATION VIDEOS AND PRODUCTS

## CLAYS BASKET HARDWARE PACKS

## HARDWARE PACK 1

- (4) 10MM X 40MM SHOULDER HEX BOLTS
- (8) 10MM x 20MM x 2MM WASHERS
- (4) 10MM ANTI-SLIP NUTS



E-Z-GO®, TXT®, RXV® are trademarks of Textron Innovations, Inc. ("Textron"). Reference to Textron's trademarks and products is only for purposes of identifying golf carts with which this Madjax product is compatible. Madjax products are aftermarket parts and are not original equipment parts. Madjax is not connected or affiliated with or sponsored by Textron.