



# CLAYS BASKET

WILL FIT CLUB CAR® PRECEDENT®  
INSTALLATION INSTRUCTIONS

**INCLUDED:**



Remove bolt cover and bolts from front struts. Retain all factory hardware. You will need it later.

1



Using retained factory hardware, attach brackets to front struts. Tighten bolts.

2



Attach clays basket to brackets on both sides using hardware pack.

3



**INSTALLATION COMPLETE**

## **PRECEDENT CLAYS BASKET HARDWARE PACKS**

### **HARDWARE PACK 1**

- (4) 10MM X 25MM SHOULDER HEX BOLTS
- (8) 10MM X 20MM X 2MM WASHERS
- (4) 10MM ANTI-SLIP NUTS