



CLAYS BASKET
WILL FIT E-Z-GO® RXV®
INSTALLATION INSTRUCTIONS

INCLUDED:



1
Remove front strut bolt cover. Remove and retain top strut bolt.



2
Attach bracket using retained hardware. *Bracket ear should be on the outside of the cart. Tighten as shown.



Attach Clays Basket using supplied hardware and tighten as shown.

3



INSTALLATION COMPLETE

CLAYS BASKET HARDWARE PACKS

HARDWARE PACK 1

- (4) 10MM X 25MM SHOULDER HEX BOLTS
- (8) 10MM X 20MM X 2MM WASHERS
- (4) 10MM ANTI-SLIP NUTS