

# RELIANCE

## POWER PARTS

### 13-090

## USB/USB-C 12V FAST CHARGER

### INSTALLATION INSTRUCTIONS

We recommend professional installation. If you choose to not have this product installed by a professional, we highly recommend that you exercise caution, care, and patience when installing this product.

#### INCLUDED WITH KIT:

- USB/USB-C
- 2 x Female Spade Connectors

#### TOOLS NEEDED:

- 1-1/8" Paddle Bit or Rotary Cutting Tool

**Note: This USB/USB-C Charger is designed to operate on 12 volts ONLY.**

1  
Locate the spot on your dash panel you wish to mount the **USB/USB-C**. Be sure to check the back side of this location for cart harness, wires, or other obstructions before cutting.

Using the ring nut on the backside of the USB as a template or a 1 1/8" Paddle Bit, drill out the hole for your USB.



2  
Notice on the backside of the USB that the two terminals are marked (+) for Positive and (-) for Negative connections.



Before attaching the power wires to the USB remove the ring nut and slide it over the wires behind the mounting location.

Then attach your 12 volt wire connections to the USB as shown.

3



Insert USB into mounting hole and secure with the ring nut.

The USB is backlit w/LED that signifies when it is on. If you do not have the USB hooked to a switched 12v source, there is a built in Power Button to turn USB on/off for constant power connections.

4

