

# 9235 Front Bumper Club Car 1981-UP DS Installation Instructions

1. Remove front bumper
2. Using drill, enlarge existing holes

Use: 3/8" drill bit

3. Install bumper

Use: (2) 3/8"-16 x 1.25" truss head bolts  
(2) 3/8" washers  
(2) 3/8"-16 nylon lock nuts

## Bill of Material

- (1) Front Bumper
- (2) 3/8"-16 x 1.25" truss head bolts
- (2) 3/8" washers
- (2) 3/8"-16 nylon lock nuts

