



Denago Nomad XL 2+2 Enclosure Installation Instructions

66176 (Black) & 66177 (Linen)



INCLUDED

- Front Track
- Driver Side Track (Front & Rear)
- Passenger Side Track (Front & Rear)
- Rear Track
- Hardware Pack
- Strut Covers (Driver & Passenger Side)
- Valences (Front, Driver Side, Passenger Side, & Rear)
- Enclosure Panels (Driver Side, Passenger Side, & Rear)


TOOLS

- Drill
- Socket Set
- Phillips Bit
- Phillips Screwdriver
- Razor
- Ratchet

STEP 1

Identify the front track. With the slot facing down, center the track on the front inside lip of the roof, and mark 3 hole locations along the flat edge of the track. Secure the track with 3 self-tapping screws.

(Note : All self-tapping screws should be screwed into the bottom lip of the roof frame)



STEP 2

Install the side tracks. There are two pieces of track per side. Starting at the front of the top, orient the track so that the track slot is on the outside. Align one of the metal tracks to the length of the top. Using a measuring tape and marker, if necessary, mark two holes where you will secure the top to the track. Secure the track to the top using the provided self-tapping screws.



STEP 3

Align the second side track with the first so the channels match, as shown. Use a measuring tape and marker, if needed, to mark the two mounting locations on the top where the track will be secured. Repeat this process on the opposite side of the vehicle to complete the side track installation.



STEP 4

To install the rear track, position it along the rear edge of the cart top, and ensure it is properly aligned. Mark the mounting locations if needed. Using the provided self-tapping screws, secure the track directly to the cart top.



STEP 5

Remove the windshield of the golf cart.



STEP 6

Wrap front strut covers around the front struts and attach with small zipper located on inside as shown. Zip all the way down.

NOTE: Windshield clip cut-outs are located on top.



STEP 7

Starting with the passenger or driver side panel, feed piping down track. Pull side panel towards rear until the front zipper is even with the zipper on the front strut cover. Connect and zip all the way down. Repeat on opposite side.



Note: When installing side and rear panels, make sure excess panel is held even with track to avoid binding when sliding panel into track.

STEP 8

For the rear panel, feed piping down the track. With hooks and storage straps on the inside, pull the rear panel so it will connect with the zipper on the side panels. Connect and zip all the way down.



STEP 9

In order to install the windshield, mark the OEM mounting hole location on top of the front strut cover. Cut a very small "X" with a razor knife to allow windshield hardware to feed through. Install windshield, and insert windshield hardware through the hole in the strut cover and into the strut.



STEP 10

Align front valence with front track, and slide into track.



STEP 11

Now that all pieces of the enclosure are installed on the cart, ensure the enclosure and valences are properly aligned to match cart body lines. When satisfied, zip all corners of the enclosure, and attach all straps with hooks to the bottom of the vehicle.



INSTALLATION COMPLETE